





## NOTE: Instructions may refer to one side of vehicle, repeat steps to the other side. If the Vehicle is fitted with a headboard bar, remove from Ute Tub (truck bed). Note: Retain hardware. Sealing factory gaps on the bed. It is recommended to use black sealant. Apply an adequate amount of sealant to the areas indicated, then smooth sealant out. Clean any excess sealant. Repeat to the other side. Place front bar assembly (FR22-FBA) over the head board. 0 0 $\subseteq$ C J G 0








# Sealing any gaps on the bed and FBA. It is recommended to use black sealant. Apply an adequate amount of sealant to the areas indicated, then smooth sealant out. Clean any excess sealant. Repeat to the other side. Sealing any gaps on the bed and FBA. It is recommended to use black sealant. Apply an adequate amount of sealant to the areas indicated, then smooth sealant out. Clean any excess sealant. Repeat to the other side.





























Use supplied Allen key to loosen the hex key screw on the catch and tension cable so it is tight but doesn't move the catch at all, then re-tighten the hex key screw.






With the lid in closed position, lift the tailgate . The tailgate must close gently against the silverback lid's seal.



If you find the tailgate is hard to close, put the tailgate down and adjust the U bolt up until the desired closing of tailgate is achieved. NOTE: the seal must touch and compress gently to achieve sealing.



## **REMOVAL OF TONNEAU COVER**



 Open tonneau cover, Detach gas strut (1) by inserting a small screwdriver and adjusting the spring clip (2) on the gas strut (1). Refer to figure 2. NOTE: Do not remove the spring clip. only a small amount of levering is required to detach.




FIGURE 2 NOTE: 2 people are required to lift and remove the tonneau cover from the vehicle.

### REPLACEMENT OF TONNEAU COVER



FIGURE 4

NOTE: 2 people are required to lift and fit the tonneau cover onto the vehicle.

 Fit tonneau cover (2) and secure hinges with hinge pins (1). Refer to figure 5.





FIGURE 5

 Remove hinge pins (1) and remove tonneau cover (2). Refer to figure 3.



 Attach gas struts (2) by clipping into place. Ensure narrow end (1)mounts to the vehicle. Refer to figure 6.




FIGURE 6

## Paint care instructions:

Your new painted Hard Tonneau Cover has been covered with a plastic film to protect the paint from damage. It will require cleaning and possibly light polishing after the protective film has been removed. Use polish as per new paint on a new vehicle. Wash Hard Tonneau Cover using water and normal carwash detergent and polish with an automotive polish.

NOTE: Please ensure Lid is kept locked at all times when not being used, for both safety and longevity.