


Fitting Instructions Part Number J100 SILVERBACK Jeep Gladiator


Check contents of kit before commencing fitment and report any discrepancies



*Image example shown only


IMPORTANT	<ul style="list-style-type: none"> • Do not stand/sit or rest heavy objects on Tonneau Cover • Humans or animals are not to be under the closed Tonneau at any given time • Securely lock tonneau Cover before operating vehicle • Tonneau Cover is not dust or water tight • Do not carry open volatile chemicals with Tonneau Cover installed • If contact with volatile chemicals occur, clean Tonneau with mild detergent and water solution 			
Care Instructions	<ul style="list-style-type: none"> • Read Instructions fully before commencing installation. • Clean Tonneau Cover with a mild detergent and water solution • Do not use abrasive cleaners or solvents • Refer to manufactures instructions applicable to power drill. • Protect Tub floor against scratches during installation process. 			
Maintenance	<p>If lubrication of the locks or hinges is required use only Graphite Powder. DO NOT use any other lubricants or oils.</p>			
Tools Required	<table style="width: 100%; border: none;"> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> • Pen / Marker • Centre Punch • Drill & Drill bits • Phillips head screwdriver • Caulking Gun • Silicon - Non Acetic </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> • Die Grinder & multi tool • Masking Tape • Scissors & Knife • Ruler • Spanner & Socket • Tape measure </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> • Soapy water solution • Allen Key set (Metric) </td> </tr> </table>	<ul style="list-style-type: none"> • Pen / Marker • Centre Punch • Drill & Drill bits • Phillips head screwdriver • Caulking Gun • Silicon - Non Acetic 	<ul style="list-style-type: none"> • Die Grinder & multi tool • Masking Tape • Scissors & Knife • Ruler • Spanner & Socket • Tape measure 	<ul style="list-style-type: none"> • Soapy water solution • Allen Key set (Metric)
<ul style="list-style-type: none"> • Pen / Marker • Centre Punch • Drill & Drill bits • Phillips head screwdriver • Caulking Gun • Silicon - Non Acetic 	<ul style="list-style-type: none"> • Die Grinder & multi tool • Masking Tape • Scissors & Knife • Ruler • Spanner & Socket • Tape measure 	<ul style="list-style-type: none"> • Soapy water solution • Allen Key set (Metric) 		

PARTS CHECK SHEET




PARTS IN MAIN CARTON

100




Tonneau Cover
Qty - 1

5



Fitting Kit
Qty - 1



PARTS IN FITTING KIT

1178




Lid Hinge
Qty - 2

1177



Hinge Bracket
Qty - 2

1177P



Hinge Pin
Qty - 2

S700-320



Gas Strut
Qty - 2

29




Strut body mount
Qty - 2

UB



Striker U-Bolt
Qty - 2

1189E



Striker Bracket
Qty - 2

CN1



Chanel nut 2 threads
Qty - 2

CN2




Chanel nut 1 thread
Qty - 2

1018



Support bracket
Qty - 2



LID NUTS AND BOLTS

25



M8x25 ALAN
Head Bolt
Qty - 12

24



M8 3mm thick
Flat Washer
Qty - 10

19




Self drilling
screws Qty - 8

23



M8
Hex Nut
Qty - 8



OTHER

42



Alan key
Qty - 1

LID-SEAL-04



D MOULD
Qty - 1




Alcohol wipe
Qty - 1





Fitting
Instruction
Qty - 1

Thoroughly clean installation areas.




Important: Instructions are for Utes with an UNDER-RAIL tubliner. If you have an OVER-RAIL tubliner you must trim the top off.

Remove front factory rail and discard.





Find centre and mark position.



Hinge mounts:

Align the hinge mounts along the front of the tray, ensuring the hinges are properly positioned from centre of tub 560 mm to centre of hinge mount either side along the inside of the front of the tub. Attach the hinges using self-drilling screws (supplied) through holes pre-drilled into the hinges. Apply clear or black silicone to any gaps, holes and between the hinges and the vehicle to prevent water entry.



Measure distance from centre on both sides and mark.




Measure and mark the positions as indicated above from the centre of the bed for placement of the bottom hinges.
WARNING: RECHECK DIMENSIONS TO ENSURE CORRECT MEASUREMENT

Hinge Mounts

Align hinge with previously marked position





NOTE





Using a 3.5MM drill bit, drill through the holes in the top and the base of the hinge plate into the tub. Remove hinge and clean any swarf, **apply Cold Galvanizing compound to the holes drilled**. Using the self-tapping screws fasten the hinge into the tub.


Slide out all side inner rail tie downs and retain.




Slide in CN1 first followed by CN2. Repeat to the other side.




Measuring 1200mm from the front inside of rail along the side rail and locate channel nut CN-1.




Measuring 710mm from the front inside of rail along the side rail and locate channel nut CN-2.



Feed m8 3mm thick washer through m8 ball stud and fasten to CN-2 channel nut.




Attach small shaft end of gas strut onto ball stud brackets, by clicking them in place.



Extrusion to finish
before hinge

LID-SEAL-04


**NOTE: SEALING LIP
MUST FACE TAILGATE**



You may cut off the desired excess at the end of your installation


Clean header rail (where extrusion will sit) with alcohol wipes provided and wipe away the residue with a dry clean cloth. Place the extrusion tape seal along the top of the header rail with the sealing lip facing towards the tailgate. Start the extrusion at the edge of the hinge. **IMPORTANT:** Position extrusion as close to the header rail rear radius. Rub down firmly to ensure maximum adhesion. (Refer to image above)

Attach lid hinges to tub hinges by
aligning and pushing the pin
through.
Click pin down into hinge locking
tab



Important:
Ensure tongues are fully inserted into the hinge slots with hinge pin securely in place.

Place lid on tub. From inside follow the assembly of hardware provided




100


Bolts are to be fitted loosely to allow for adjustment in the next step.

ASSEMBLY ORDER


	100
	1018
	1178
	24
	M8 BOLT



Adjust Lid so it is even on both sides and pull the lid back all the way so the front of the hinge bottoms out to the inside front lip of the lid.



Note: Image showing lid in upside down position




Note: Pull lid back all the way so the front of the hinge bottoms out of the inside front of the lid.


With the lid in adjusted position, crawl into the tub and tighten all 8 bolts to 3nm torque

With the Hard Tonneau Cover opened, attach the cylinder end of each gas strut onto the mounting brackets attached to the Hard Tonneau Cover by clicking into place

Attach the gas struts between the lid and the mounting brackets.




Fasten bracket 1189E into position using m8x25mm pan head bolt.





Loosen 2 screws and slide catch to align correctly with latch bar. Tighten screws to secure in place.

Adjust nuts on latch bar to alter height of bar to suit.


Repeat for the opposite side.



Use an Allen key to loosen the hex key screw on the catch and tension cable so it is tight but doesn't move the catch at all, then re-tighten the hex key screw.




With the lid in closed position, lift the tailgate. The tailgate must close gently against the silverback lid's seal.





If you find the tailgate is hard to close, put the tailgate down and adjust the U bolt up until the desired closing of tailgate is achieved. NOTE: the seal must touch and compress gently to achieve sealing.


HOW TO OPERATE YOUR SILVERBACK LID




Open the tailgate



Now gently pull on the yellow release cable, so the rotary latch releases.





Aid the lid up, the gas springs will take over and it will lift it all the way.




Close the lid.

Push each corner of the lid down so the rotary latch is engaged.



Close the tailgate



REMOVAL OF TONNEAU COVER




FIGURE 1

1. Open tonneau cover, Detach gas strut (1) by inserting a small screwdriver and adjusting the spring clip (2) on the gas strut (1). Refer to figure 2. NOTE: Do not remove the spring clip, only a small amount of levering is required to detach.




FIGURE 2

NOTE: 2 people are required to lift and remove the tonneau cover from the vehicle.

2. Remove hinge pins (1) and remove tonneau cover (2). Refer to figure 3.




FIGURE 3

REPLACEMENT OF TONNEAU COVER




FIGURE 4

NOTE: 2 people are required to lift and fit the tonneau cover onto the vehicle.

1. Fit tonneau cover (2) and secure hinges with hinge pins (1). Refer to figure 5.




FIGURE 5

2. Attach gas struts (2) by clipping into place. Ensure narrow end (1) mounts to the vehicle. Refer to figure 6.




FIGURE 6

Paint care instructions:

Your new painted Hard Tonneau Cover has been covered with a plastic film to protect the paint from damage. It will require cleaning and possibly light polishing after the protective film has been removed. Use polish as per new paint on a new vehicle. Wash Hard Tonneau Cover using water and normal carwash detergent and polish with an automotive polish.

NOTE: Please ensure Lid is kept locked at all times when not being used, for both safety and longevity.

J100 Jeep Gladiator

SILVERBACK



Part Description	Part Number	Quantity/ Length	CHECK LIST
LID FRONT HINGES	1178	2	
LID TUB MOUNT WITH PINS	1177	2	
GAS STRUTS	S700-320	2	
STRUT BALL	29	2	
M8 U BOLT	UB	2	
LOCK STRICKER BRACKETS	1189E	2	
SPACER BRACKET	1018	2	
LID NUTS & BOLTS			
M8 BOLTS	25	12	
M8 WASHER (3MM THICK)	24	10	
SELF DRILLING SCREWS	19	10	
M8 NUTS	23	8	
CHANEL NUT 2 THREAD LOCATION	CN1	2	
CHANEL NUT 1 THREAD LOCATION	CN2	2	
OTHER			
ALLEN KEY	42	1	
D MOULD	LID-SEAL-01	2 X 300MM	
ALCHOLE WIPE		1	
FITTING INSTRUCTIONS MANUAL		1	